




Location of nameplate

NTE-182 AIS TRANSPONDER

JHS-182 AIS

NCM-779 AIS CONTROLLER



NTE-182: Serial number JHS-182: Serial number NCM-779: Serial number





Immediately

No	Equipment	Name	Serial number
1	AIS	JHS-182	BB51401 -
2	AIS TRANSPONDER	NTE-182	BB71401 -

NTE-183 AIS TRANSPONDER

JHS-183 AIS

NCM-983 AIS CONTROLLER



NTE-183: Serial number JHS-183: Serial number NCM-983: Serial number

Immediately

No	Equipment	Name	Serial number
1	AIS TRANSPONDER	NTE -183	- BE04000
2	AIS CONTROLLER	NCM-983	- BB04206